


This section deals with basic maintenance of the Q1 locomotive

Your Q1 steam locomotive will benefit from lubricating the following points marked on the photograph below.



Please note that during handling or removing from its protective packaging, the drive shaft may become dislodged from its working position. Do not worry, this is perfectly normal and doesn't allow the model's components to break. Simply visually align the drive shaft with its receptor and push back onto place holding the tender as level as possible during the process.

DCC Fitting

For fitting DCC to this engine, please examine the instructions that can be found in our DCC section of this web site.

Servicing

If you require an 'out of warranty' service or repair for this locomotive, please send it to our official service agent BR Lines.

BR Lines

97, Park Lane

Guisborough

Cleveland